



INSTALLATION PROCEDURE:

1. SET 1.5"x1.5"x42" POSTS @ 10'0" O.C. AND EXCAVATE A 6"x6" TRENCH, SET POST DOWNSLOPE. INSTALL ADDITIONAL POSTS AS REQUIRED AT LOW POINTS.
2. SECURE WIRE MESH TO POSTS WITH ADEQUATE STAPLES OR WIRE TIES.
3. ATTACH FILTER FABRIC TO WIRE MESH AND EXTEND DOWN INTO TRENCH AS DETAILED.
4. BACKFILL AND COMPACT TRENCH TO SECURE FILTER FABRIC.
5. IN LIEU OF WIRE MESH AND FILTER FABRIC, CONTRACTOR MAY USE A PREFABRICATED SEDIMENT FENCE EQUAL TO:
 - A. ENVIROFENCE(MIRAFI)
 - B. PROPLEX SILT STOP(AMOCO)
 - C. ECONOFENCE(TERRATEX)
 - OR APPROVED EQUALS.

NOTE:

SEDIMENT FENCE IS TO BE CHECKED AFTER EVERY STORM EVENT AND/OR ONCE EVERY TWO WEEKS (MIN.)

SCALE N.T.S.	CITY OF TORRINGTON Engineering Department
APPROVED	
RV. DATE JAN. 2002	CONSTRUCTION SILT FENCE
MAY 2004	
AUG. 2011	